

This document describes some examples of AMP commands supported by the Shogun Studio AMP server

Type	Code	Name	Description	Response
0x2	0x00	Stop	Send the Serial Control STOP command. Stops any recording or playback. Timecode parameter is only processed when stopping a recording.	Ack – command successful. Nak – Invalid command.
0x2	0x01	Play	If the Shogun device is not in playback mode, reboot into playback and the last file recorded or the indexed file will play. If the Shogun device is in playback mode play the currently loaded file or the indexed file.	Ack – command successful. Nak – Invalid command.
0x2	0x02	Record	If the Shogun device is not in record mode, reboot into capture mode and start recording. If the Shogun device is in record mode, start recording. Timecode paramter may be used to define when the record starts.	Ack – command successful. Nak – Invalid command.
0x2	0x03	StandbyOff	No action. Respond with Ack.	Ack – command received. Nak – Invalid command.
0x2	0x10	FastForward	If in record mode, no action. If in playback mode, fast forward the current clip at 16x playback rate.	Ack – command successful. Nak – Invalid command.